


SB-2500B MANUAL HOOD RAISE PROCEDURE

THE HOOD CAN BE RAISED BY TWO METHODS, EITHER THE HOOD RAISE SWITCH WHICH IS POWERED BY A POWER PACK OR BY THE HAND JACK (FIGURE 1). COMPLETE INSTRUCTIONS ARE PROVIDED FOR THIS PROCEDURE, ON A DECAL (FIGURE 2), JUST BESIDE THE HAND JACK (FIGURE 1).



(FIGURE 1.)

HOOD RAISE & LOWER OPERATION
POWERED CONNECT RAISE & LOWER HOSES TO CORRESPONDING RAISE & LOWER CONNECTIONS ON SOLENOID VALVE & OPERATE HOOD WITH TOGGLE SWITCH
MANUAL TO RAISE: DISCONNECT RAISE HOSE FROM SOLENOID VALVE, CONNECT TO MALE QUICK DISCONNECT ON HAND PUMP. DISCONNECT LOWER HOSE FROM SOLENOID VALVE. CONNECT TO RETURN HOSE. INSERT HANDLE & PUMP TO LOWER: USE 2-WAY VALVE TO RELIEVE PRESSURE ON HAND PUMP HOSE. REVERSE RAISE & LOWER HOSES. INSERT HANDLE & PUMP

(FIGURE 2.)